

RING

TIP UREĐAJA: Magnetni bicikl

MODEL UREĐAJA : RX 112


Maksimalna težina korisnika: 120KG

Klasa upotrebe: H

Klasa tačnosti: C



UPUTSTVO ZA MONTAŽU I UPOTREBU



Sadržaj

Važne sigurnosne napomene

Ekspandirani crtež

Popis delova

Montiranje

Uputstvo za ekran

Instrukcije za vežbanje

1
2,3
4
5,6
7
8,9

VAŽNO!


PAŽLJIVO PROČITAJTE OVO UPUTSTVO PRE UPOTREBE BIKIKLA.

Dragi kupče,

Molimo vas da pažljivo pročitate ovo uputstvo pre upotrebe.


VAŽNE SIGURNOSNE NAPOMENE:

- Obratite pažnju na sledeće mere predostrožnosti pre sklapanja ili rukovanja mašinom
- Montirajte mašinu tačno kao što je opisano u uputstvu za upotrebu.
- Pre prve upotrebe mašine proverite sve zavrtnje, matice i druge priključke i proverite da li je trenažer u bezbednom stanju.
- Postavite mašinu na suvom mestu i podalje od vlage i vode.
- Postavite odgovarajuću podlogu (npr. gumenu podlogu, drvenu dasku itd.) ispod mašine u području montaže kako biste izbegli prljavštinu i sl.
- Pre početka treninga, uklonite sve objekte u krugu od 2 metra od mašine.
- Za čišćenje mašine nemojte koristiti agresivne proizvode za čišćenje. Koristite samo priložene alate ili sopstvene alate za montažu ili popravke bilo kog dela mašine. Odmah ukloniti kapljice znoja sa mašine.
- Vaše zdravlje može biti ugroženo nepravilnim ili prekomernim treningom. Konsultujte lekara pre početka programa obuke. On može definisati maksimalne paramtere (puls, vati, trajanje treninga itd.) po kojim možete trenirati i dobiti precizne informacije tokom treninga. Ova mašina nije pogodna za terapijske svrhe.
- Trenirajte na mašini samo kada je u ispravnom stanju. Koristite samo originalne rezervne delove za sve potrebne popravke.
- Ovu mašinu može koristiti samo jedna osoba u jednom trenutku.
- Nosite obuću i obuću koja je pogodna za treninge sa mašinom. Vaša obuća treba da bude prikladna za trenažer.
- Ako imate osećaj vrtoglavice, bolesti ili druge abnormalne simptome, molimo vas da prestanete da trenirate i konsultujte lekara
- Ljudi kao što su deca i hendikepirana lica treba da koriste mašinu samo u prisustvu druge osobe koja može pružiti pomoć i savet.
- Snaga mašine se povećava sa povećanjem brzine i obrnuto. Mašina je opremljena podešivim dugmetom za podešavanje otpora. Smanjite otpor okretanjem dugmeta za podešavanje otpora prema koraku 1. Povećajte otpor okretanjem dugmeta za podešavanje otpora u odnosu na stepen 8. Maksimalna težina korisnika je 100kg / 220lbs.
- Prilikom podizanja ili pomeranja opreme treba paziti da ne povredite leđa. Uvek koristite odgovarajuće tehnike podizanja i/ili potražite pomoć.



POPIS DELOVA:


BR	OPIS	KOL	R	OPIS	KOL
1	Ekran	1	37	Prateći prsten D12	2
2	Ekstenziona žica	1	38	Magnetni blok za fiksiranje	1
3	Postolje rukohvata	1	39	Magnet	4
4	Regulator otpora	1	40	Vučna opruga	1
5	Krstasti vijak sa ravno-lećastom	1	41	Krstasti vijak sa ravno-lećastom	5
6	Zakrivljena podloška D5	1	42	Matica	3
7	Zakrivljena podloška Ø.5 xØ20x2	6	43	Šestougaoni vijak M6x60	1
8	Opružna podloška D8	4	44	Matica	1
9	Šestougaoni vijak sa ravno-lećastom	6	45	Labava izolovana podloška	1
10	Rukohvat	1	46	Matica sa dva žleba	1
11	Sunđer rukohvata	2	47	Postolje kugličnog ležaja	2
12	Sedište	1	48	Žleb kugličnog ležaja	2
13	Postolje sedišta	1	49	Matica sa tri žleba	1
14	Podloška Ø8	3	50	Podloška	1
15	Najlonska matica M8	3	51	Točak kaiša	1
16L	Leva pedala	1	52	Okrugli magnet	1
16R	Desna pedala	1	53	Kaiš	1
17	Zadnji stabilizator	1	54	Najlonska matica	1
18	Poklopac zadnjeg stabilizatora	2	55	Podloška	1
19	Četvrtasi vijak	4	56	Čaura jednosmernog ležaja	1
20	Zakrivljena podloška Ø10x Ø20x2.0	4	57	Jednosmerni ležaj	1
21	Acorn matica M10	4	58	Šestougaoni vijak sa cilindričnom	1
22	Prednji stabilizator	1	59	Šestougaoni vijak sa cilindričnom	1
23	Prednji stabilizator	2	60	Krstasti vijak sa ravno-lećastom	8
24	Glavni ram	1	61	Krstasti vijak sa ravno-lećastom	5
25	Donja žica za regulisanje otpora	1	62	Senzorna žica	1
26	Zamajac	1	63	Poluga	1
27	Osovina zamajca	1	64L	Levi poklopac lanca	1
28	Sedište ležaja	2	64R	Desni poklopac lanca	1
29	Ležaj 6001Rs	2	65	Poklopac za otvor poluge	2
30	Blok ležaja	2	66	Ručka	1
31	Šestougaoni vijak M6x9	6	67	Čausra postolja sedišta	1
32	Podloška	4	68	Okrugli zadnji poklopac	2
33	Šestougaoni vijak M6x15	4	69	Šestougaoni ključ	1
34	Magnetna ploča	1	70	Multifunkcionalni ključ	1
35	Osovina magnetne ploče	1	71	Vijak M5x10	2
36	Opružna podloška D6	2	72	Merač pulsa za rukohvatu	2
73	Ravna podloška *φ12*1	2	74	Krstasti šraf ST4.2*20	2

PRIČVRSNSI ELEMENTI:**PRIPREMA:**

A. Pre montaže uverite se da ćete imati dovoljno prostora oko mašine.

B. Upotrebite obezbeđene alate za montažu.

C. Pre montaže proverite da li su svi potrebni delovi dostupni (gore u ovom uputstvu možete naći detaljni crtež sa svim pojedinačnim delovima (označeni brojevima), od kojih se ova mašina sastoji.


UPUTSTVO ZA SKLAPANJE**KORAK 2:**


Provucite regulator otpora (4) kroz rukohvat (3), a zatim ga fiksirajte krstastim vijom (5), zakrivljenom podloškom (6)

1. Prvo povežite ekstenzionu žicu (2) i senzorsku žicu (62), a zatim povežite žicu otpora (4) sa donjom žicom otpora (25).
2. Spojite postolje rukohvata (3) na glavni ram (24) šestougaonim vijkom (9), opružnom podloškom (8) i zakrivljenom podloškom (7).

KORAK 1:

Učvrstite prednji (22) i zadnji stabilizator (17) na glavni ram (24) kvadratnim vijkom (19), zakrivljenom podloškom (20) i maticom (21).





**KORAK 3:**


1. Učvrstite rukohvat (10) na postolje rukohvata (3) šestougaonim vijkom (9) i zakrivljenom podloškom (7)

KORAK 4:

1. Povežite žicu ekrana (1) sa ekstenzionom žicom (2), žicom za puls (72). Zatim učvrstite ekran (1) na postolje rukohvata (3) krstastim vijkom (71)

**KORAK 5:**

1. Učvrstite sedište (12) na postolje sedišta (13) najlonskom maticom (15) i podloškom (14).
2. Zatim ubacite sastavljeno postolje sedišta (13) u glavni ram (24), podesite sedište na odgovarajuću visinu, a zatim fiksirajte opružnom ručicom (66).



**KORAK 6:**

Učvrstite levu i desnu pedalu (16L/R) na polugu (63)



OPREZ: UVERITE SE DA STE ZATEGLI SVE VIJKE I MATICE PRE VEŽBANJA.

NAPOMENA: ZADNJI POKLOPAC NA PREDNJEM STABILIZATORU JE POKRETAN, ŠTO VAM OLAKŠAVA DA POMERATE BIKIKL, A ZADNJI POKLOPAC NA ZADNJEM STABILIZATORU MOŽE PODESITI PARALELNOST.

UPUTSTVO OTPORA ZA VEŽBANJE

Okrenite dugme za zatezanje (17) u smeru kazaljke na satu da biste povećali nivo otpora, okrenite u suprotnom smeru od smera kazaljke na satu da biste smanjili nivo otpora. Nivo 1 je najniži, a nivo 8 najviši

UPUTSTVO ZA KOMPJUTER ZA VEŽBANJE**FUNKCIONALNI TASTER:**

MODE – Pritisnite da odaberete funkcije.

SET – Da podesite vreme, rastojanje, kalorije kada nije u režimu scan.

RESET – Da resetujete vreme, rastojanje, kalorije.

– Držite 3 sekundi da resetujete vreme, rastojanje, kalorije.

FUNKCIJE I RAD:

1. SCAN: Pritisnite taster MODE dok se ne pojavi „SCAN“, monitor će se rotirati kroz sledeće funkcije: vreme, kalorije, brzina, udaljenost, ukupna udaljenost. Svaki prikaz će se zadržati 4 sekundi.
2. TIME(TMR): Odbrojava ukupno vreme od početka do kraja vežbanja.
3. SPEED(SPD): Prikazuje trenutnu brzinu.
4. DISTANCE(DST): Odbrojava rastojanje od početka do kraja vežbanja.
5. CALORIES(CAL): Broj ukupnih kalorija od početka do kraja vežbanja.
6. TOTAL DISTANCE(ODO): Računa ukupno rastojanje nakon ugradnje baterija.
8. AUTO ON/OFF & AUTO START/STOP
Bez ikakvog signala u trajanju od 4 minuta, napajanje će se automatski isključiti.

Kada se točak pokrene ili pritiskom na taster, monitor se pokreće.

9. ALARM

Funkcije vremena, udaljenosti i kalorija mogu se podesiti odbrojavanjem, bilo koja od gornjih vrednosti ide na nulu, računar će oglasiti alarm 5 sekundi.

SPECIFIKACIJE:

FUNKCIJA	AUTO SCAN	Svakih 4 sekundi
	VREME(TMR)	0:00~99:59 (minuta:sekundi)
	TRENTNA BRZINA(SPD)	Maksimalni signal je 999.9KM/H ili Mile/H
	RASTOJANJE(DST)	0~999.9KM ili Miles
	KALORIJE(CAL)	0~9999Kcal
	UKUPNO RASTOJANJE (ODO)	0~999.9KM ili Miles
TIP BATERIJE		2 kom veličine AAA ili UM-4
RADNA TEMPERATURA		0°C~+40°C (32°F~104°F)
TEMPERATURA SKLADIŠTENJA		-10°C~+60°C(14°F~168°F)

SMERNICE I INSTRUKCIJE ZA UPOTREBU

Sledeće smernice će vam pomoći da planirate svoj program vežbanja. Zapamtite da su pravilna ishrana i adekvatan odmor od suštinskog značaja za uspešne rezultate. Ako počinjete program vežbanja, treba da proverite sa svojim lekarom ako:

- Imate dijagnostikovane srčane probleme, visoki krvni pritisak ili bilo koji drugi zdravstveni problem
- Niste vežbali više od godinu dana.
- Ste stariji od 35 godina, a trenutno ne vežbate
- Ste trudni
- Imate dijabetes.
- Imate bolove u grudima ili vrtoglavicu
- Oporavljate se od povrede ili bolesti

Ciljni otkucaji srca (THR)

GODINE	ZONA TRENINGA
	MIN-MAX (BPM)
20	133 - 167
25	132 - 166
30	130 - 164
35	129 - 162
40	127 - 161
45	125 - 159
50	124 - 156
55	122 - 155
60	121 - 153
65	119 - 151
70	118 - 150
75	117 - 147
80	115 - 146
85	114 - 144


Napomena: Ovo je samo vodič i učinak će zavistiti od kondicije i stanja (zdravlja) osobe koja koristi bicikl

UPUTSTVA ZA VEŽBANJE

Upotreba bicikla će vam pružiti nekoliko pogodnosti. On će poboljšati vašu fizičku kondiciju, tonirati vaše mišiće i zajedno sa ishranom kojom kontrolirate kalorije, pomoći će vam da izgubite na težini.


1. FAZA ZAGREVANJA

Ova faza pomaže da krv bolje struji po telu i mišići rade ispravno. Takođe će smanjiti rizik od grčeva i povreda mišića. Preporučljivo je uraditi nekoliko vežbi istezanja kao što je prikazano ispod. Svako istezanje treba da se drži oko 30 sekundi, ne prisiljavajte ili trzajte mišiće - ako boli, ZAUSTAVITE SE.



2. FAZA VEŽBANJA

Ovo je faza kada ulažete napor. Nakon redovne upotrebe, mišići u nogama postaju fleksibilniji. Radite sopstvenim tempom i obavezno održavajte stalan tempo tokom vežbanja. Stopa rada bi trebalo da bude dovoljna da podigne otkucaje srca u ciljnu zonu prikazanu na grafikonu ispod



Ova faza treba da traje najmanje 12 minuta iako većina ljudi počinje sa oko 15-20 minuta

3. FAZA HLAĐENJA

Ova faza je da se vaš kardiovaskularni sistem i mišići spuste. Ovo je ponavljanje vežbe zagrevanja, npr. smanjite tempo, nastavite oko 5 minuta. Vežbe istezanja bi sada trebalo da ponavite, ponovo se sećajući da ne prisiljavate ili forsirate mišiće.

Kako stičete kondiciju, možda ćete morati da trenirate duže i jače. Preporučuje se da trenirate najmanje tri puta nedeljno, a ako je moguće, ravnomerno rasporedite vežbe tokom cele nedelje.

TONIRANJE MIŠIĆA

Da biste poboljšali tonus mišića dok ste na biciklu, moraćete da imate dovoljno visok otpor. To će dodatno opteretiti naše mišiće nogu i može značiti da ne možete trenirati onoliko dugo koliko želite. Ako takođe

pokušavate da poboljšate svoju kondiciju, morate da promenite svoj program obuke. Morate trenirati normalno tokom faza zagrevanja i hlađenja, ali na kraju faze vežbanja treba da povećate otpor, čineći da vaše noge rade više neog uobičajeno. Možda ćete morati da smanjite brzinu da biste zadržali otkucaje srca u ciljnoj zoni.

MRŠAVLJENJE

Važan faktor ovde je količina napora koji ste uložili. Što teže i duže radite, više ćete kalorija sagoreti. Efektivno, to je isto kao da ste trenirali kako bi poboljšali svoju kondiciju, razlika je samo cilj.

KAKO INSTALIRATI BATERIJE:

1. Postavite dve baterije na zadnju stranu monitora.
2. Proverite da li su baterije pravilno postavljene, a opruge baterija u kontaktu sa baterijama.
3. Ako je ekran nečitljiv ili se pojavljuju samo delimični segmenti, uklonite baterije i ponovo ih instalirajte.
4. Kad god izvadite baterije, sve vrednosti funkcija će se vratiti na nulu.

ODRŽAVANJE I TRETMAN

1. Proverite da li su svi zavrtnji i navrtke pravilno zaključani i okretni delovi treba slobodno da se okreću bez oštećenja delova.
2. Očistite opremu sapunom i samo malo vlažnom krpom. Molimo vas da ne koristite rastvarače za čišćenje opreme.


KVAROVI I TRETMAN

Kvar	Razlog	Tretiranje
Baza je nestabilna.	<ol style="list-style-type: none"> 1. Pod nije ravan ili postoji mali objekat ispod prednjeg ili zadnjeg stabilizatora. 2. Poklopci zadnjeg stabilizatora nisu 	<ol style="list-style-type: none"> 1. Uklonite objekat 2. Podesite poklopce zadnjeg stabilizatora
Upravljač ili jastuk sedišta se tresu.	Zavrtnji i ručka sedla su labavi	Zategnite zavrtnje i ručku sedla
Glasna buka iz pokretnih delova	Interval delova nije dobro zategnut	Otvorite poklopce da podesite
Nema otpora kada se vozi bicikl	<ol style="list-style-type: none"> 1. Interval magnetske otpornosti raste 2. Tenziona kontrola je oštećena 3. Traka za trčanje klizi 4. Noseći set je oštećen 	<ol style="list-style-type: none"> 1. Otvorite poklopce da podesite 2. Promenite tenzionu kontrolu 3. Otvorite poklopce da podesite 4. Promenite noseći set

RING**TIP UREĐAJA: Magnetni bicikl****MODEL: RX 112****Maksimalna težina korisnika: 120KG**

Klasa upotrebe: H

Klasa točnosti: C

**UPUTE ZA SASTAVLJANJE I UPOTREBU****SADRŽAJ:**

Važne sigurnosne napomene	1
Prošireni crtež	2,3
Popis dijelova	4
Montaža	5,6
Prikaz uputa	7
Upute za korištenje	8,9


VAŽNO!**PAŽLJIVO PROČITAJTE OVAJ PRIRUČNIK PRIJE KORIŠTENJA BICIKLA.**

Dragi kupče,
Prije uporabe pažljivo pročitajte ovaj priručnik.

VAŽNE SIGURNOSNE NAPOMENE:

- Pridržavajte se sljedećih mjera opreza prije sastavljanja ili rada stroja
- Sastavite stroj točno onako kako je opisano u korisničkom priručniku.
- Prije prve uporabe stroja, provjerite sve vijke, matice i ostale spojeve i uvjerite se da je trenažer u sigurnom stanju.
- Postavite stroj na suho mjesto i dalje od vlage i vode.
- Postavite odgovarajuću površinu (npr. gumenu podlogu, drvenu dasku itd.) ispod stroja u području sastavljanja kako biste izbjegli prljavštinu itd.
- Prije početka treninga uklonite sve predmete unutar 2 metra od sprave.
- Nemojte koristiti agresivna sredstva za čišćenje za čišćenje stroja. Koristite samo isporučene alate ili vlastite alate za sastavljanje ili popravak bilo kojeg dijela stroja. Odmah uklonite kapljice znoja sa stroja.
- Vaše zdravlje može biti ugroženo nepravilnim ili pretjeranim treningom. Posavjetujte se s liječnikom prije početka programa treninga. Može definirati maksimalne parametre (otkucaje srca, vati, trajanje treninga itd.) pomoću kojih možete trenirati i dobiti precizne informacije tijekom treninga. Ovaj stroj nije prikladan za terapijske svrhe.
- Vježbajte na stroju samo kada je u dobrom stanju. Za sve potrebne popravke koristite samo originalne rezervne dijelove.
- Ovaj stroj može koristiti samo jedna osoba istovremeno.
- Nosite cipele i čizme koje su prikladne za vježbanje sa spravom. Vaša obuća mora biti prikladna za trenera.
- Ako osjećate vrtoglavicu, mučninu ili imate druge abnormalne simptome, molimo prekinite trening i obratite se liječniku
- Osobe kao što su djeca i osobe s invaliditetom smiju koristiti stroj samo u prisutnosti druge osobe koja može pružiti pomoć i savjet.
- Snaga stroja raste s povećanjem brzine i obrnuto. Stroj je opremljen podešivim gumbom za podešavanje otpora. Smanjite otpor okretanjem gumba za podešavanje otpora na korak 1. Povećajte otpor okretanjem gumba za podešavanje otpora na korak 8. Maksimalna težina korisnika je 100 kg / 220 lbs.
- Prilikom podizanja ili pomicanja opreme pazite da ne ozlijedite leđa. Uvijek koristite odgovarajuće tehnike dizanja i/ili potražite pomoć.


PROŠIRENI CRTEŽ



LISTA DIJELOVA

BR	OPIS	KOL	R	OPIS	KOL
1	Zaslon	1	37	Prateći prsten D12	2
2	Ekstenzijska žica	1	38	Magnetski blok za pričvršćivanje	1
3	Postolje rukohvata	1	39	Magnet	4
4	Regulator otpora	1	40	Vučna opruga	1
5	Križni vijak s ravno-lećastom glavom	1	41	Križni vijak s ravno-lećastom glavom	5
6	Zakrivljena brtva D5	1	42	Navrtka	3
7	Zakrivljena brtva Ø.5 xØ20x2	6	43	Šesterokutni vijak M6x60	1
8	Opružna brtva D8	4	44	Navrtka	1
9	Šesterokutni vijak s ravno-lećastom	6	45	Labava izolirana brtva	1
10	Rukohvat	1	46	Navrtka s dva žlijeba	1
11	Spužva rukohvata	2	47	Postolje kugličnog ležaja	2
12	Sjedalo	1	48	Žlijeb kugličnog ležaja	2
13	Postolje sjedala	1	49	Navrtka s tri žlijeba	1
14	Brtva Ø8	3	50	Brtva	1
15	Najlonska navrtka M8	3	51	Kotač remena	1
16L	Lijeva pedala	1	52	Okrugli magnet	1
16R	Desna pedala	1	53	Remen	1
17	Stražnji stabilizator	1	54	Najlonska navrtka	1
18	Poklopac stražnjeg stabilizatora	2	55	Brtva	1
19	Četvrtasi vijak	4	56	Čahura jednosmjernog ležaja	1
20	Zakrivljena brtva Ø10x Ø20x2.0	4	57	Jednosmjerni ležaj	1
21	Acorn matica M10	4	58	Šesterokutni vijak s cilindričnom	1
22	Prednji stabilizator	1	59	Šesterokutni vijak s cilindričnom	1
23	Prednji stabilizator	2	60	Križni vijak s ravno-lećastom glavom	8
24	Glavna rama	1	61	Križni vijak s ravno-lećastom glavom	5
25	Donja žica za reguliranje otpora	1	62	Senzorska žica	1
26	Zamašnjak	1	63	Poluga	1
27	Osovina zamašnjaka	1	64L	Lijevi poklopac lanca	1
28	Sjedalo ležaja	2	64R	Desni poklopac lanca	1
29	Ležaj 6001Rs	2	65	Poklopac za otvor poluge	2
30	Blok ležaja	2	66	Ručka	1
31	Šesterokutni vijak M6x9	6	67	Čahura postolja sjedala	1
32	Brtva	4	68	Okrugli stražnji poklopac	2
33	Šesterokutni vijak M6x15	4	69	Šesterokutni ključ	1
34	Magnetska ploča	1	70	Multifunkcijski ključ	1
35	Osovina magnetske ploče	1	71	Vijak M5x10	2
36	Opružna brtva D6	2	72	Mjerač pulsa na rukohvatu	2
73	Ravna brtva *φ12*1	2	74	Križni vijak ST4.2*20	2

PRIČRŠĆIVAČI




1.PRIPREMA:

A. Prije sastavljanja, provjerite imate li dovoljno prostora oko stroja.

B. Koristite priložene alate za sastavljanje.

C. Prije sklapanja provjerite jesu li dostupni svi potrebni dijelovi (iznad u ovom priručniku možete pronaći detaljan crtež sa svim pojedinačnim dijelovima (numeriranim) od kojih se ovaj stroj sastoji.

UPUTE ZA SASTAVLJANJE



KORAK 1.


Pričvrstite prednji (22) i stražnji stabilizator (17) na glavnu ramu (24) kvadratnim vijkom (19), zakrivljenom brtvom (20) i navrtkom (21).

KORAK 2.


1. Provucite regulator otpora (4) kroz rukohvat (3), a zatim ga pričvrstite križnim vijkom (5), zakrivljenom brtvom (6)

2. Najprije povežite ekstenzijsku žicu (2) i senzorsku žicu (62), a zatim povežite žicu otpora (4) s donjom žicom otpora (25).


3. Spojite postolje rukohvata (3) na glavnu ramu (24) šesterokutnim vijkom (9), opružnom podloškom (8) i zakrivljenom brtvom (7).


**KORAK 4.**

Povežite žicu zaslona (1) s ekstenzijskom žicom (2), žicom za puls (72). Zatim pričvrstite zaslon (1) na postolje rukohvata (3) križnim vijkom (71)

**KORAK 3.**

Pričvrstite rukohvat (10) na postolje rukohvata (3) šesterokutnim vijkom (9) i zakrivljenom brtvom (7)




**KORAK 5.**

1. Pričvrstite sjedalo (12) na postolje sjedala (13) najlonskom navrtkom (15) i brtvom (14).
2. Zatim ubacite sastavljeno postolje sjedala (13) u glavnu ramu (24), namjestite sjedalo na odgovarajuću visinu, a zatim pričvrstite opružnom ručicom (66).

KORAK 4.

Pričvrstite lijevu i desnu pedalu (16L/R) na polugu (63).




OPREZ: PRIJE VJEŽBE OBAVEZNO ZATEZNITE SVE VRTKE I MATICE.

NAPOMENA: STRAŽNJI POKLOPAC NA PREDNJEM STABILIZATORU JE POKRETAN, ŠTO OMOGUĆAVA LAKO POKRETANJE BIKIKLA, A STRAŽNJI POKLOPAC NA STRAŽNJEM STABILIZATORU MOŽE PODEŠAVATI PARALELNOST.

RAČUNALNI VODIČ ZA VJEŽBE

SMJERNICE ZA OTPOR VJEŽBANJU



Okrenite gumb za zatezanje (17) u smjeru kazaljke na satu kako biste povećali razinu otpora, okrenite suprotno od kazaljke na satu kako biste smanjili razinu otpora. Razina 1 je najniža, a razina 8 najviša

SMJERNICE I UPUTE ZA UPORABU

Sljedeće smjernice pomoći će vam u planiranju vašeg programa vježbanja. Ne zaboravite da su pravilna prehrana i adekvatan odmor ključni za uspješne rezultate. Ako započinjete s programom vježbanja, trebali biste provjeriti sa svojim liječnikom ako:

Dijagnosticirani su vam srčani problemi, visoki krvni tlak ili bilo koji drugi zdravstveni problem

Niste vježbali više od godinu dana.

Stariji ste od 35 godina i trenutno ne vježbate

Trudni ste

Imate dijabetes.

Imate bol u prsima ili vrtoglavicu

CILJNI OTKUCAJI SRCA (THR)

DOB	ZONA TRENINGA
	MIN-MAX (BPM)
20	133 - 167
25	132 - 166
30	130 - 164
35	129 - 162
40	127 - 161
45	125 - 159
50	124 - 156
55	122 - 155
60	121 - 153
65	119 - 151
70	118 - 150
75	117 - 147
80	115 - 146
85	114 - 144

Napomena: Ovo je samo smjernica i performanse će ovisiti o kondiciji i stanju (zdravlju) osobe koja koristi bicikl

UPUTE ZA VJEŽBU

Korištenje bicikla će vam pružiti nekoliko prednosti. Poboľšat će vašu tjelesnu kondiciju, tonirati mišiće i uz dijetu s kontroliranim unosom kalorija pomoći u mršavljenju.


1. FAZA ZAGRIJAVANJA

Ova faza pomaže boljem protoku krvi kroz tijelo i pravilnom radu mišića. Također će smanjiti rizik od grčeva mišića i ozljeda. Preporuča se napraviti neke vježbe istezanja kao što je prikazano u nastavku. Svako istezanje treba držati oko 30 sekundi, nemojte forsirati ili trzati mišiće – ako vas boli, STANITE.



2. FAZA VJEŽBE

Ovo je faza kada ulažete trud. Nakon redovite uporabe mišići na nogama postaju fleksibilniji. Radite vlastitim tempom i budite sigurni da održavate ravnomjerno tempo tijekom cijele vježbe. Brzina rada trebala bi biti dovoljna da podigne broj otkucaja srca u ciljnu zonu prikazanu na grafikonu ispod



Ova faza bi trebala trajati najmanje 12 minuta, iako većina ljudi počinje s otprilike 15-20 minuta

3. FAZA HLAĐENJA

Ova faza je za opuštanje vašeg kardiovaskularnog sustava i mišića. Ovo je ponavljanje vježbe zagrijavanja, npr. smanjite tempo, nastavite oko 5 minuta. Sada biste trebali ponoviti vježbe istezanja, opet imajući na umu da ne smijete forsirati ili naprezati mišiće.

Kako stječete kondiciju, možda ćete trebati trenirati dulje i jače. Preporuka je da trenirate najmanje tri puta tjedno, a ako je moguće, rasporedite vježbe ravnomjerno kroz tjedan.

TONIZIRANJE MIŠIĆA

Kako biste poboljšali mišićni tonus dok ste na biciklu, morat ćete imati dovoljno visok otpor. To će dodatno opteretiti naše mišiće nogu i može značiti da ne možete trenirati onoliko dugo koliko biste željeli. Ako i vi pokušavate poboljšati svoju kondiciju, trebate promijeniti program treninga. Morate normalno trenirati tijekom faza zagrijavanja i hlađenja, ali na kraju faze vježbe trebali biste povećati otpor, tako da vaše noge rade više nego inače. Možda ćete morati usporiti kako biste zadržali broj otkucaja srca u ciljnoj zoni.

GUBITAK TEŽINE

Važan faktor ovdje je količina truda koji ulažete. Što više i duže radite, to ćete više kalorija sagorjeti. U biti, to je isto kao da trenirate kako biste poboljšali svoju kondiciju, jedina razlika je cilj.

KAKO INSTALIRATI BATERIJE:

1. Stavite dvije baterije na stražnju stranu monitora.
2. Provjerite jesu li baterije ispravno postavljene i jesu li opruge baterija u kontaktu s baterijama.
3. Ako je zaslon nečitljiv ili se pojavljuju samo djelomični segmenti, izvadite baterije i ponovno ih umetnite.
4. Kad god izvadite baterije, sve vrijednosti funkcija vratit će se na nulu.

ODRŽAVANJE I LIJEČENJE

1. Provjerite jesu li svi vijci i matice dobro pričvršćeni i trebaju li se rotirajući dijelovi slobodno okretati bez oštećenja dijelova.
2. Očistite opremu sapunom i blago vlažnom krpom. Nemojte koristiti otapala za čišćenje opreme.

Kvar	Razlog	Tretiranje
Baza je nestabilna.	3. Pod nije ravan ili postoji neki objekt ispod prednjeg ili stražnjeg stabilizatora. 4. Poklopci stražnjeg stabilizatora nisu poravnani tijekom montiranja.	3. Uklonite objekt 4. Namjestite poklopce stražnjeg stabilizatora
Upravljač ili jastuk sjedala se tresu.	Vijci i ručka sjedala su labavi	Zategnite vijke i ručku sjedala
Glasna buka iz pokretnih dijelova	Interval dijelova nije dobro zategnut	Otvorite poklopce radi namještanja
Nema otpora kada se vozi bicikl	5. Interval magnetske otpornosti raste 6. Kontrola opterećenja je oštećena 7. Traka za trčanje klizi 8. Noseći set je oštećen	5. Otvorite poklopce radi namještanja 6. Promijenite kontrolu opterećenja 7. Otvorite poklopce radi namještanja 8. Promijenite noseći set

RING


TYPE OF DEVICE: Magnetic bicycle

MODEL: RX 112

Maximum user weight: 120KG

Usage class: H

Accuracy class: C



THE CONTENT

Important security eg	1
Expanded drawing	2,3
Parts list	4
Mounting	5,6
Display instructions	7
Instructions for use	8,9

IMPORTANT!


READ THIS MANUAL CAREFULLY BEFORE USING THE BICYCLE

Dear customer,
Please read this manual carefully before use.

IMPORTANT SAFETY NOTES:


- Observe the following precautions before assembling or operating the machine
- Assemble the machine exactly as described in the user manual.
- Before using the machine for the first time, check all screws, nuts and other connections and make sure that the trainer is in a safe condition.
- Place the machine in a dry place away from moisture and water.
- Place a suitable surface (eg rubber mat, wooden board, etc.) under the machine in the assembly area to avoid dirt, etc.
- Before starting training, remove all objects within 2 meters of the device.
- Do not use aggressive cleaning agents to clean the machine. Use only the supplied tools or your own tools to assemble or repair any part of the machine. Immediately remove any drops of sweat from the machine.
- Your health can be endangered by improper or excessive training. Consult your doctor before starting a training program. It can define maximum parameters (heart rate, watts, duration of training, etc.) with which you can train and get precise information during training. This machine is not suitable for therapeutic purposes.
- Exercise on the machine only when it is in good condition. For all necessary repairs, use only original spare parts.
- This machine can only be used by one person at a time.
- Wear shoes and boots that are suitable for exercising with the device. Your footwear must be appropriate for the trainer.
- If you feel dizzy, nauseous or have other abnormal symptoms, please stop training and consult a doctor
- Persons such as children and persons with disabilities may only use the machine in the presence of another person who can provide help and advice.
- Engine power increases with increasing speed and vice versa. The machine is equipped with an adjustable resistance adjustment knob. Decrease resistance by turning the resistance adjustment knob to step 1. Increase resistance by turning the resistance adjustment knob to step 8. Maximum user weight is 100 kg / 220 lbs.
- When lifting or moving equipment, be careful not to injure your back. Always use proper lifting techniques and/or get help.

EXPANDED DRAWING AND PARTS LIST:




PARTS LIST

nb	DESCRIPTION		nb	DESCRIPTION	
1	Screen	1	37	Companion ring D12	2
2	Extension cord	1	38	Magnetic block for attachment	1
3	Handle base	1	39	Magnet	4
4	Resistance regulator	1	40	Traction spring	1
5	Phillips screw with flat-lens head	1	41	Phillips screw with flat-lens head	5
6	Curved gasket D5	1	42	Nut	3
7	Curved seal Ø.5 xØ20x2	6	43	Hexagonal screw M6x60	1
8	Spring seal D8	4	44	Nut	1
9	Hexagonal screw with flat-lens head	6	45	Loose insulated gasket	1
10	Handrail	1	46	Nut with two grooves	1
11	Sponge handle	2	47	Ball bearing base	2
12	Seat	1	48	Ball bearing groove	2
13	Seat base	1	49	Nut with three grooves	1
14	Gasket Ø8	3	50	Seal	1
15	Nylon nut M8	3	51	Belt wheel	1
16L	Left pedal	1	52	Round magnet	1
16R	Right pedal	1	53	Belt	1
17	Rear stabilizer	1	54	Nylon nut	1
18	Rear stabilizer cover	2	55	Seal	1
19	Square screw	4	56	One-way bearing sleeve	1
20	Curved seal Ø10x Ø20x2.0	4	57	One-way bearing	1
21	Acorn nut M10	4	58	Hexagonal screw with cylindrical	1
22	Front stabilizer	1	59	Hexagonal screw with cylindrical	1
23	Front stabilizer	2	60	Phillips screw with flat-lens head	8
24	Main frame	1	61	Phillips screw with flat-lens head	5
25	Lower wire for adjusting the	1	62	Sensor wire	1
26	Flywheel	1	63	Lever	1
27	Flywheel shaft	1	64L	Left chain cover	1
28	Bed seat	2	64R	Right chain cover	1
29	Bearing 6001Rs	2	65	Lever opening cover	2
30	Bearing block	2	66	Lunch	1
31	Hexagon screw M6x9	6	67	Seat base bushing	1
32	Seal	4	68	Round back cover	2
33	Hexagonal screw M6x15	4	69	Hex key	1
34	Magnetic plate	1	70	Multi-function key	1
35	The axis of the magnetic plate	1	71	Screw M5x10	2
36	Spring seal D6	2	72	Heart rate monitor on the handle	2
73	Flat gasket *φ12*1	2	74	Cross screw ST4.2*20	2

FASTENERS**PREPARATION:**


- Before assembly, make sure that you will have enough space around the machine.
- Use the assembly tools provided.
- Before assembly, check that all the necessary parts are available (above in this manual you can find a detailed drawing with all the individual parts (numbered), which this machine consists of).

ASSEMBLY INSTRUCTIONS:**STEP 1:**

Attach Front (22) and Rear Stabilizer (17) to Main Frame (24) with Square Bolt (19), Curved Gasket (20), and Nut (21)

Step 2


- Put the resistance regulator (4) through the handle (3) and then secure it with the Phillips screw (5), curved gasket (6)
- Connect the extension wire (2) and sensor wire (62) first, then connect the resistance wire (4) to the lower resistance wire (25).
- Attach the handle base (3) to the main frame (24) with the hex bolt (9), spring washer (8), and curved gasket (7).

**STEP 2:**


1. Put the resistance regulator (4) through the handle (3) and then secure it with the Phillips screw (5), curved gasket (6)
2. Connect the extension wire (2) and sensor wire (62) first, then connect the resistance wire (4) to the lower resistance wire (25).
3. Attach the handle base (3) to the main frame (24) with the hex bolt (9), spring washer (8), and curved gasket (7).


STEP 3:

1. Attach the handle (10) to the handle base (3) with the hex screw (9) and the curved gasket (7).

**STEP 4:**

- Connect the display wire (1) to the extension wire (2), pulse wire (72). Next, attach the screen (1) to the handle base (3) with the Phillips screw (71)



**STEP 5:**


1. Attach the seat (12) to the seat base (13) with a nylon nut (15) and a gasket (14).

Next, insert the assembled seat base (13) into the main frame (24), adjust the seat to the appropriate height, and then secure with the spring-loaded handle (66)

STEP 6:


Attach the left and right pedals (16L/R) to the lever (63).

Note: attach the left pedal counterclockwise and the right pedal clockwise.



CAUTION: MAKE SURE TO TIGHTEN ALL BOLTS AND NUTS BEFORE EXERCISE.

NOTE: THE BACK COVER ON THE FRONT STABILIZER IS MOVABLE, WHICH MAKES IT EASY TO MOVE THE BIKE AND THE BACK COVER ON THE REAR STABILIZER CAN ADJUST THE PARALLELITY.

GUIDELINES FOR EXERCISE RESISTANCE

Turn the tension knob (17) clockwise to increase the resistance level, turn counterclockwise to decrease the resistance level. Level 1 is the lowest and level 8 is the highest

EXERCISE COMPUTER GUIDE**FUNCTION KEY:**

MODE – Press to select functions.

SET – To set time, distance, calories when not in scan mode.

RESET – To reset time, distance, calories.

–Hold for 3 seconds to reset time, distance, calories.

FUNCTIONS AND OPERATION:

1. SCAN: Press the MODE key until "SCAN" appears, the monitor will rotate through the following functions: time, calories, speed, distance, total distance. Each display will be held for 4 seconds.

2. TIME(TMR): Counts the total time from the beginning to the end of the exercise.

3. SPEED(SPD): Displays current speed.

4. DISTANCE (DST): Counts the distance from the beginning to the end of the exercise.

5. CALORIES (CAL): Number of total calories from the beginning to the end of exercise.

6. TOTAL DISTANCE (ODO): Calculates the total distance after installing the batteries.

8. AUTO ON/OFF & AUTO START/STOP

Without any signal for 4 minutes, the power will automatically turn off.

When the wheel is turned or a button is pressed, the monitor starts.

9. ALARM

The functions of time, distance and calories can be set by countdown, any of the above values go to zero, the computer will sound an alarm for 5 seconds.

SPECIFICATIONS:

FUNCTION	AUTO SCAN	Every 4 seconds
	TIME(TMR)	0:00~99:59 (minute:second)
	CURRENT SPEED (SPD)	The maximum signal is 999.9KM/H or Mile/H
	DISTANCE (DST)	0~999.9KM or Miles
	CALORIES (CAL)	0~9999Kcal
	TOTAL DISTANCE (ODD)	0~999.9 KM or Miles
	AUTO SCAN	Every 4 seconds
BATTERY TYPE		2 pcs size AAA or UM-4
WORKING TEMPERATURE		0°C~+40°C (32°F~104°F)
STORAGE TEMPERATURE		-10°C~+60°C(14°F~168°F)

GUIDELINES AND INSTRUCTIONS FOR USE

The following guidelines will help you plan your exercise program. Remember that proper nutrition and adequate rest are essential for successful results. If you are starting an exercise program, you should check with your doctor if:

You have been diagnosed with heart problems, high blood pressure or any other health problem

You haven't exercised in over a year.

You are older than 35 years and are not currently exercising

You are pregnant

You have diabetes.

You have chest pain or dizziness

You are recovering from an injury or illness.

Target Heart Rate (THR)

AGE	TRAINING ZONE
	MIN-MAX (BPM)
20	133 - 167
25	132 - 166
30	130 - 164
35	129 - 162
40	127 - 161
45	125 - 159
50	124 - 156
55	122 - 155
60	121 - 153
65	119 - 151
70	118 - 150
75	117 - 147
80	115 - 146
85	114 - 144


Note: This is only a guide and performance will depend on the fitness and condition (health) of the person using the bike

EXERCISE INSTRUCTIONS


Using a bicycle will provide you with several benefits. It will improve your physical condition, tone your muscles and, together with a calorie-controlled diet, help you lose weight.

1. WARM-UP PHASE

This phase helps the blood flow better throughout the body and the muscles work properly. It will also reduce the risk of muscle cramps and injuries. It is recommended to do some stretching exercises as shown below. Each stretch should be held for about 30 seconds, do not force or jerk the muscles - if it hurts, STOP.

**2. EXERCISE PHASE**

This is the stage where you put in the effort. After regular use, the muscles on the legs become more flexible. Work at your own pace and be sure to maintain an even pace throughout the exercise. The speed of work should be enough to raise the heart rate into the target zone shown in the graph below



This phase should last at least 12 minutes, although most people start with about 15-20 minutes

3. COOLING PHASE

This phase is for relaxing your cardiovascular system and muscles. This is a repetition of the warm-up exercise, eg. reduce the pace, continue for about 5 minutes. Now you should repeat the stretching exercises, again keeping in mind not to force or strain the muscles.

As you gain fitness, you may need to train longer and harder. It is recommended that you train at least three times a week, and if possible, spread the exercises evenly throughout the week.

MUSCLE TONING

In order to improve muscle tone while on the bike, you will need to have a sufficiently high resistance. This will put additional stress on our leg muscles and may mean that you cannot train for as long as you would like. If you are also trying to improve your fitness, you need to change your training program. You must train normally during the warm-up and cool-down phases, but at the end of the exercise phase you should increase the resistance, so that your legs work harder than usual. You may need to slow down to keep your heart rate in the target zone.

WEIGHT LOSS

An important factor here is the amount of effort you put in. The harder and longer you work, the more calories you will burn. In essence, it's the same as training to improve your fitness, the only difference is the goal.

HOW TO INSTALL BATTERIES:

1. Place two batteries on the back of the monitor.
2. Check that the batteries are correctly installed and that the battery springs are in contact with the batteries.
3. If the display is unreadable or only partial segments appear, remove the batteries and reinsert them.
4. Whenever you remove the batteries, all function values will reset to zero.

MAINTENANCE AND TREATMENT

1. Check that all screws and nuts are properly locked and the rotating parts should turn freely without damaging the parts.
2. Clean the equipment with soap and a slightly damp cloth. Please do not use solvents to clean the equipment.

FAILURES AND TREATMENT

Failure	Reason	Treatment
The base is unstable.	The floor is not level or there is an object under the front or rear stabilizer.	Remove the object Fit the rear stabilizer covers
Steering wheel or seat cushion shakes.	The rear stabilizer covers are not aligned during assembly.	Tighten the bolts and the seat handle
Loud noise from moving parts	The screws and seat handle are loose	Open the covers for adjustment
There is no resistance when riding a bicycle	The interval of the parts is not properly tightened	Open the covers for adjustment Change the load control Open the covers for adjustment Change the bearing set